

Ring Light White LED

with intensity adjustment control



Quality of Inspection

LED illuminator containing high power white LED lamps for a various incident light applications. Homogenous illumination at pure day-light white colour. Detachable diffuser filter for extra smooth and soft illumination is included. Integrated ON-OFF switch and brightness control.



Ring Light is powered directly via AUX output of Inspectis Digital Microscopes for excellent cable management. Attachable Polariser/Analyser filter set for removing glare and extra power supply for compatibility to other devices are provided as accessories.

Specification:

Number of LEDs / Colour Temperature	8 pcs high power lamps / 5800 K
Mounting Diameter	φ62mm and φ72mm
Working distance	80–500 mm. (50-500 mm with diffuser)
Controller	On-board with On/Off and electronic dimmer
Operating / Storage Environment	5°– +55°C, 20 - 85% RH, non-condensing
Size / Weight	φ 110(OD)x φ73(ID)x 20(H) mm, 0.2 kg.

Ordering Number/Name

- HD-024-B** RingLight White LED
- HD-024-P-C** Polarisation filter set for Ring Light, 58mm (for C12)
- HD-024-P-U** Polarisation filter set for Ring Light, 67mm (for U10 and F30)
- HD-024-S** External Power Supply (optional)

Reseller:



V1, 2019

www.inspect-is.com